

Why bother?

- Not part of minimum guidelines – Watering: frequency, amount, and type of water
- Plants do not respond to amount of water supplied
- Plants respond to water availability



Capacitance sensors

- Based on same principle as TDR
- Measurements are simplified
- No expensive electronics needed









| 9 | electromagnetic fi |
|---|---------------------------------|
| | |
| | The second second second second |



| ECHO-5 | 70 MHz |
|--------------|---------|
| ECHO-10 | 20 MHz |
| ECHO-20 | 20 MHz |
| ECHO-TE | 70 MHz |
| ThetaProbe | 100 MHz |
| SM200 | 100 MHz |
| W.E.T sensor | 20 MHz |
| CS616/625 | 70 MHz |



























Francesco Montesano, Stephanie Burnett